
Replacing Trampoline Springs

A HANDY GUIDE


Caution: When replacing springs, please be aware of sharp hooks and always wear protective gloves when carrying out trampoline maintenance.



To remove the old springs, take the spring tool by the handle and guide the hooked end onto the spring hook located in the frame. Use your upper body strength to pull the spring tool upwards and towards you, releasing the spring from its hole in the top frame.



Using a spring Tool



Using a spring

STEP 2

If you are removing all the springs to replace them with a complete new set, we recommend alternating as you go so the tension is evenly distributed around the bed. Whatever you remove from one point, ensure you mirror this on the opposite side.



Attaching new springs:

Attaching New Springs: Please note that each spring will have a standard hook and an elongated hook. The standard hook attaches to the steel bed triangle whilst the elongated hook goes into the frame.

Using your spring tool, pull the new spring towards the frame ensuring that the hook lines up with the corresponding slot in the steel frame.


Using your hand, push down on the body of the spring until it slots into the frame. Finally, release the spring tool from the spring hook and repeat this process for any remaining springs.



Adult installation required

Read User Guide before assembling

Please keep this guide for further reference





N.B.: If you are fitting a complete set of new springs, we recommend working around the trampoline as if it were a compass; fit springs at North then South, East then West, mirroring each side as you go.

Continue to fit the remaining springs in this manner so that the tension remains evenly distributed through the trampoline bed and springs.

